

Processing Steps

1) Separately heat Phase 1 and 2 to 85-90°C with moderate mixing

2) Add Phase 2 to

3) Add Phase 3 to combined Phase 1 & 2

4) Add Phase 2 to

5) At 85°C add Phase

6) Hold temperature

7) Cool to 70°C

8) Hold temperature

9) Add Phase 3 to combined Phase 1 & 2